

PERFORMANCE DATA NO LOAD AND NO DOOR OPENINGS AT MID-POINT CONTROL SETTING				
Type A With Run/Start Capacitor	65°F (18°C) Ambient		90°F (32°C) Ambient	
Operating Time	25 to 35%		45 to 55%	
Freezer Temperature	2° to 8°F -17° to -13°C		0° to 5°F -18° to -15°C	
Refrigerature Temperature	35° to 40°F 2° to 4°C		35° to 40°F 2° to 4°C	
Low Side Pressure (cut-in)	8 to 16 psig 55 to 110 kPa		8 to 16 psig 55 to 110 kPa	
Low Side Pressure (cut-out)	1 to 4 psig 7 to 28 kPa		1 to 4 psig 7 to 28 kPa	
High Side Pressure (Last 1/3 of cycle)	110 to 120 psig 758 to 827 kPa		150 to 175 psig 1034 to 1207 kPa	
Wattage (Last 1/3 of cycle)	140 to 185		140 to 185	
Amps (Running)	1.1 to 1.6		1.1 to 1.6	
Base Voltage	115 VAC		115 VAC	
DEFROST SPECIFICATIONS				
Cabinet Size	Thermostat		Heater	
	Cut-in	Cut-out	Watts	Ohms
18'	25°F -4°C	47°F 8°C	375	35
Defrost 30 Minutes Every 10 Hours of Compressor Run Time				
CONDENSER FAN MOTOR				
Watts	RPM		Amps	
2.3	1100 CW Opposite Shaft		.15 Running	
ICE MAKER SPECIFICATIONS				
Electrical	115 Volts		60 Hertz	
Thermostat	Opens at 48°F (9°C)		Closes at 15°F (-9°C)	
Heater Wattage	165			
ICE MAKER CONNECTOR PLUG CONNECTIONS				
Wire Number	Wire Color		Connects to:	
1	Green/Yellow		Ground	
2	Yellow		Water Valve	
3	Black		Line	
4	Lt. Blue		Neutral	

SERVICE DATA SHEET - 240379004

R134a

STANDARD - AUTOMATIC DEFROST

TOP FREEZER MODELS


IMPORTANT SAFETY NOTICE

The information provided herein is designed to assist qualified repair personnel only. Untrained persons should not attempt to make repairs due to the possibility of electrical shock. Disconnect power cord before servicing.

IMPORTANT

If any green grounding wires are moved during servicing, they must be returned to their original position and properly secured.

CAUTION: All electrical parts and wiring must be shielded from torch flame. Do not allow torch to contact insulation; it will char at 200°F and flash ignite (burn) at 500°F. Excessive heat will distort the plastic liner.




ICE MAKER INFORMATION

Test Cycling


Remove cover by inserting screwdriver in notch at bottom and prying cover from housing. Use screwdriver to rotate motor gear counterclockwise until *Holding Switch* circuit is completed. All components of ice maker should function to complete the cycle.

Water Fill Volume

The water fill adjustment screw will change the fill time. One full turn is equal to 20cc (.68 oz.). The correct fill is 102 to 130cc (3.4 to 4.3 oz.). When a water valve is replaced, the fill volume must be checked.




Pictorial Schematic



240398801

Ladder Schematic



NOTE
----- DENOTES NOT ALL MODELS

Compressor Wiring

